

## Auger

An auger expands the functionality of your telehandler. Not only can the machine go up in the air but also down into the ground. With various auger bit sizes available, the operator can be precise in choosing one to best fit the task at hand.

### Features

- Auger Drive Motor Part No. 1001092816 & Adapter Part No. 6043600  
Required for SkyTrak and Lull E-Series applications
- Auger Drive Motor Part No. 51012 Required for Lull C-Series applications



### Auger Bits

**Current Production - Auger Bits**  
Available Through JLG Aftermarket Parts

DIAMETER		6 to 18 in.	
DEPTH		48 in.	
PART NO.		1001242616	
MODEL		SN BREAKS	LOAD CHART BOOKLET
JLG	G5-18A	with the Universal (skid steer) quick coupler 0160040809 - Present	1001126677

**Non-Current Production - Auger Bits, SkyTrak**  
Available Through JLG Aftermarket Parts

DIAMETER		6 in.		9 in.		12 in.		15 in.		18 in.		24 in.	
DEPTH		50 in.		50 in.		50 in.		50 in.		50 in.		50 in.	
PART NO.		8866415		8866416		8866417		8866418		8866419		8866420	
MODEL		SN BREAKS		LOAD CHART BOOKLET									
SKYTRAK	6036	Prior To 0160031200		Consult Factory		•		•		•		•	
	6042	Prior To 0160031200		Consult Factory		•		•		•		•	
	8042	Prior To 0160031235		Consult Factory		•		•		•		•	
	10042	Prior To 0160031425		Consult Factory		•		•		•		•	
	10054	Prior To 0160031255		Consult Factory		•		•		•		•	

**Non-Current Production - Auger Bits, Lull**  
Available Through JLG Aftermarket Parts

DIAMETER		6 in.		9 in.		12 in.		15 in.		18 in.		24 in.		8 in.		12 in.		16 in.		18 in.	
DEPTH		50 in.		50 in.		50 in.		50 in.		50 in.		50 in.		60 in.		60 in.		60 in.		60 in.	
PART NO.		8866415		8866416		8866417		8866418		8866419		8866420		10166297		10166298		10166994		10166299	
MODEL		SN BREAKS		LOAD CHART BOOKLET																	
LULL	644E-42	Prior To 0160031500		7300628		•		•		•		•		•		•		•		•	
	944E-42	Prior To 0160031500		7301586		•		•		•		•		•		•		•		•	
	1044C-54 SII	Prior To 0160037893		1001105327		•		•		•		•		•		•		•		•	

#### NOTES:

- Use only JLG approved attachments with proper material handler model/attachment load capacity charts displayed in the operator's cab.
  - Never use your attachment as a work platform or personnel carrier.
- Can't find the attachment you are looking for? Contact your JLG Aftermarket Parts representative at 1-877-JLG-LIFT or visit [www.jlg.com](http://www.jlg.com).

Auger Extensions

**Non-Current Production - Auger Extensions, SkyTrak**  
Available Through JLG Aftermarket Parts

LENGTH				24 in.
PART NO.				8866423
	MODEL	SN BREAKS	LOAD CHART BOOKLET	
SKYTRAK	6036	Prior To 0160031200	Consult Factory	•
	6042	Prior To 0160031200	Consult Factory	•
	8042	Prior To 0160031235	Consult Factory	•
	10042	Prior To 0160031425	Consult Factory	
	10054	Prior To 0160031255	Consult Factory	



NOTES:

- Use only JLG approved attachments with proper material handler model/attachment load capacity charts displayed in the operator's cab.
  - Never use your attachment as a work platform or personnel carrier.
- Can't find the attachment you are looking for? Contact your JLG Aftermarket Parts representative at 1-877-JLG-LIFT or visit [www.jlg.com](http://www.jlg.com).